



Micro Listener™

Listen in on secret conversations

Ages 6 and Up
10048

Requires 1 357 (LR44)
button cell battery, included.


**Important: Please save this instruction sheet.
It contains valuable product information.**

Listen in on secret conversations with the
SpyX Micro Listener

How to play with your SpyX Micro Listener


- 1) Unclip the Earbud and unwrap the cord
- 2) Move the on/off switch to on (Fig 1)
- 3) Gently place the ear bud into your ear
- 4) Clip your Micro Listener to the inside of your pocket so the Sound Dish is pointing outwards. (Fig 2)

Tip: When you are done playing make sure you turn off the
SpyX Micro Listener



BATTERY SAFETY INFORMATION

- Requires one LR44 button-cell battery, included.
- Only adults should install and replace batteries.
- Do not recharge non-rechargeable batteries.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- The supply terminals are not to be short circuited.
- Do not use rechargeable batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Do not mix old and new batteries.
- Only the batteries of the same or equivalent type recommended to be used.
- Do not dispose batteries in a fire; they may explode.
- Dispose of batteries safely




ATTENTION ADULTS—TO REPLACE BATTERIES

The SpyX Micro Listener requires one LR44 button-cell
battery, included.

1. Use a small Phillips head screwdriver to loosen the screw on
the battery compartment. The screw will not fall out. (Fig 3)
2. Open battery cover. Remove exhausted battery.
3. Place new battery in compartment as shown
4. Replace the battery cover and tighten screw.

NOTE: This unit has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this unit does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the unit and receiver.
- Connect the unit into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.



**Warning: Changes or modifications to these units
not expressly approved by the party
responsible for compliance could void the user's
authority to operate the equipment.**

Product specifications subject to change.
MICRO LISTENER 10048-IS-US



IF YOU HAVE ANY QUESTIONS, PLEASE
CONTACT US AT
www.atomicmonkeyproducts.com/help

⚠ WARNING:
CHOKING HAZARD: Small Parts.
Not for Children Under 3 Years.