



ROLL-IN VOICE BOMB™

Surprise Intruders!

Ages 6 and up
10525
SpyX Roll-in Voice Bomb

Requires two AA (LR06)
batteries, not included.

**Important: Please save this instruction sheet.
It contains valuable product information.**

Roll-in Voice Bomb to Surprise Intruders!

1. Turn on the Roll-in Voice Bomb by moving the on-off switch to the "ON" position (fig. 2)
2. To Record A Message: press and hold the red recording button until you hear one beep sound ("beep") and then record a message. When you finish your message, release the red button and you will hear another double beep sound ("beep beep") which means recording is finished.

Note: Once the voice bomb is turned off the recorded message will be erased and you will need to record another message.

3. Place the Roll-in Voice Bomb in any location (desk, shelf, doorway) to catch intruders when they walk by. Or even roll it in to a room already occupied! It automatically turns upright and is ready for action.
4. When any of the 4 the motion sensors detect movement your message will be played back!

Tip: When finished playing with the Roll-in Voice Bomb please move the power switch to the "off" position.

BATTERY SAFETY INFORMATION

- Only adults should install and replace batteries.
- Do not recharge non-rechargeable batteries.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- The supply terminals are not to be short circuited.
- Do not use rechargeable batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only the batteries of the same or equivalent type recommended to be used.
- Do not dispose of batteries in a fire; they may explode.
- Dispose of batteries safely.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to these units not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ATTENTION ADULTS—TO INSTALL AND REPLACE BATTERIES

SpyX ROLL-IN VOICE BOMB requires two AA (LR06) batteries, not included.

- Use a small Phillips head screwdriver to loosen the screw and remove the battery cover (Fig. 2).
- Remove all old batteries.
- Place new batteries in compartments as shown (Fig. 2).
- Replace the battery cover and tighten screw.




Fig. 1





Fig. 2



**IF YOU HAVE ANY QUESTIONS, PLEASE
CONTACT US AT
www.atomicmonkeyproducts.com/help**

Product specifications subject to change.
SPYX ROLL-IN VOICE BOMB
10525-IS-US

WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.